



This Issue Sponsored by

oMósaic

Messages for Manufacturing Personnel http://www.aiche.org/CCPS/Publications/Beacon/index.aspx

July 2015

Know When to Leave

n April 1995, a manufacturing plant in New Jersey was preparing a product blend that included sodium hydrosulfite, aluminum powder, potassium carbonate (all solid materials), and a small amount of benzaldehyde (a liquid). The mixing was done in a 6-m³ blender. An exothermic reaction occurred, which was likely triggered by water contamination. Employees were evacuated from the building, but later several workers returned and attempted to empty the blender. While they were doing this, the blender exploded (Photo 1), killing five employees who were in the blender room and injuring four others.

In April 2004, an operator in a batch polyvinylchloride plant in Illinois inadvertantly opened a valve on the wrong reactor. The reactor was in the reaction phase of the process and contained vinyl chloride monomer under pressure. A large cloud of flammable, toxic vinyl chloride was released into the building. Operators and a shift supervisor tried in vain to stop the release, and did not evacuate. The flammable cloud ignited and exploded, destroying the plant (Photo 2). There were five fatalities (including the operators who were trying to stop the release) and three injuries. For more information on this incident, see the June 2013 Beacon.

In June 2005, a fire broke out in a gas-cylinder filling and distribution facility in St. Louis, MO (Photo 3). The facility contained thousands of cylinders of flammable gas. A relief valve on a propylene cylinder opened on the extremely hot day, and the released gas ignited, starting the fire. The fire spread rapidly, engulfing most of the facility within 4 minutes, and caused other cylinders to explode. All people in the facility evacuated immediately and the fire department did not attempt to enter. Although the death of one neighbor was attributed to an asthma attack triggered by smoke, there were no fatalities among the site workers and visitors who promptly evacuated.



What Can You Do?

In the first two incidents, workers were fatally injured when attempting to respond to a serious abnormal event — an unexpected exothermic reaction in a vessel, and a large release of flammable vapor into a building. It is likely that they thought they could save the day, but either had insufficient information or didn't consider the risk. In the third incident, workers and visitors promptly evacuated the facility, firefighters maintained a safe distance from the fire, and there were no fatalities among the workers, visitors, or firefighters.

You cannot know when an unexpected reaction in a vessel might develop enough pressure to cause the vessel to rupture. All a large release of a flammable vapor needs in order to burn or explode is an ignition source. Never put yourself in danger by remaining in the area if this happens in your plant. Know your facility's emergency plans, participate in drills, and know when to evacuate or shelter in a safe place.

Know what can go wrong in your plant, when you should evacuate, and when to shelter in place!

©AIChE 2015. All rights reserved. Reproduction for non-commercial, educational purposes is encouraged. However, reproduction for any commercial purpose without express written consent of AIChE is strictly prohibited. Contact us at ccps_beacon@aiche.org or 646-495-1371.